



ACCESSORIES

i-com Series UPS Accessories

i-com Series UPS Accessories

Model: RM2020



UPS remote monitoring panel

- 4x20 character LCD display
- RS485 input port (for long distance)
- RS232 input port
- RS232 output port + dry contact port
- Emergency Stop Input

Model: US-4 & US-8



UPS multiserver shutdown unit
(Dry contact multiplexer)

- RS232 input port
- RS232 Output
- 4 or 8 multiplexed dry contact output

Model: ML100



Serial port multiplexer for UPS and STS

- RS232 input port
- 2 x DB9 type socket RS232 outputs
- External or internal

Model: ML200



Internal Serial port multiplexer for UPS and STS

- RS232 input port
- DB9 type socket RS232 output
- RJ45 Ethernet output (TCP/IP)



ACCESSORIES

i-com Series UPS Accessories

i-com Series UPS Accessories

Model: SNMP



External SNMP adaptor for UPS

- WEB based monitoring & management
- SNMP management
- Multi server shutdown
- Multi UPS monitoring

Model: RSX24



External RS232 to RS485 converter for UPS and STS


- For long distance communication
- Bi-directional operation
- 4 wire RS485 output (Half & full duplex)

Model: RS-NET



External RS232 to TCP/IP converter for UPS and STS

- Monitoring & management over TCP/IP



ACCESSORIES

i-com Series UPS Accessories

i-com Series UPS Accessories

Model: MDX2



External MODBUS over RS485 adaptor for UPS and STS

- For SCADA and BMS connection
- MODBUS RTU protocol
- 2 wire RS485 output
- 8 bit hardware addressable

Model: MDX-NET



External MODBUS over TCP/IP adaptor for UPS and STS

- For SCADA and BMS connection
- MODBUS TCP protocol
- RJ45 Ethernet output
- 8 bit hardware addressable

Model: GM-1



External GSM modem for UPS

- For SMS option
- SNMP compability
- Control via AT commands
- Configuration by the SNMP web interface
- Push-push SIM card installation



ACCESSORIES

i-com Series UPS Accessories

Model: GM-2



External GSM / GPRS modem for UPS

- SMS option
- Monitoring & management via GPRS and SMS
- Directly UPS connection
- Smart modem
- Push-push SIM card installation
- Easy configuration by the Utility PC software

Model: GM-3



External GSM / GPRS modem for UPS
with Internal battery unit

- SMS option
- Monitoring & management via GPRS and SMS
- Directly UPS connection
- Smart modem
- Push-push SIM card installation
- Easy configuration by the Utility PC software
- Uninterruptible communication with internal battery

Model: GMB1



External Battery Unit for GM-2 Modem

- This unit is the external battery bank for GM-2 modem.